

Connecting a Digital Set Top Box through VCR.

Turn the power off-

Unplug the antenna cable from the VCR and plug it into the 'antenna in' socket on the set top box ...Then, connect the coloured cords from the 'A/V out' socket on the set top box to the 'A/V or Video in' sockets at the back of the VCR. Don't even have to change any of the connections between the VCR and TV.

Turn the TV on and switch to the channel that you watch your VCR on.

Don't forget to select A/V on the VCR so you can see the set top box search for new channels.

ABC 1- is channel 20 you need to go up one channel up to get ABC 2, it's - channel 22.

Connecting *with new Digital TV*

If you have a new Digital TV- this already has a built in digital Receiver, so you don't need a set top box. It still needs to be tuned to ABC2 on channel 22.

Connecting a Digital Set Top Box through DVD Player

Turn the power off ...

Plug the antenna into the Digital Set Top Box and take the cords from the 'A/V out socket' on the back of the set top box into one of the 'A/V in' sockets at the back of the TV . Then turn the power back on and select the AV input on the TV.

Scan channels on the Digital Set Top Box and select channel 22 for ABC2.